



A \_\_\_\_\_ inches. B \_\_\_\_\_ inches. C \_\_\_\_\_ inches.  
 D \_\_\_\_\_ inches. E \_\_\_\_\_ inches. F \_\_\_\_\_ inches.  
 G \_\_\_\_\_ inches. H \_\_\_\_\_ inches. I \_\_\_\_\_ inches.  
 J \_\_\_\_\_ inches. K \_\_\_\_\_ inches.  
 L \_\_\_\_\_ degrees. M \_\_\_\_\_ degrees.  
 N \_\_\_\_\_ degrees. O \_\_\_\_\_ degrees.

To measure the angles of the corners lay 15' of rope or string from the corner in each direction the fence will be. This will give you a more accurate angle on the protractor. Next lay a protractor on one of the ropes across the bottom where it reads 0 degrees. Next read on the protractor where the other rope is and record it on this sheet.

Example:

